



RENEW KEY FUNCTION


1. SMALL KEY




Lift Pin 25



Lift Pin 7




Connect Pin 19



Connect to Board GND

1a. USA Version



Remove Jumper

2. CHROME KEY

